

IMPORTANT:

Your MacRepeater is shipped in installation mode. You must run it's built in setup wizard before it can be used.

Wait at least 40 seconds after plugging in the MacRepeater before trying to connect to it. It needs to boot up.

To run the setup wizard connect to the MacRepeater wirelessly and launch any web browser (Safari, Firefox, etc). Then type the address `http://192.168.10.1` into the web browser's address bar. This is not a website. It is the hardwired address of the MacRepeater's built-in setup wizard.

If your web browser offers a dialog stating your are not connected to the internet, ignore it — you do not need to be connected to the internet to setup the MacRepeater.

The MacRepeater will ask you for a login and password, both are 'admin'.

The setup wizard can be launched by clicking on the first item in the left hand menu of the resulting page. The password the wizard will ask you for is your existing networks password — do not try and create a new password for the MacRepeater. All other network settings will be filled out for your by the setup wizard.

For more information about the setup process see section E of the included manual "Setting up the MacRepeater."

